



INSERT INSTALLATION INSTRUCTIONS

GOODE Skis are designed not to require special screw inserts. However, should a screw be stripped from a ski, follow the following directions:

Tools Required:

- GOODE special plastic insert(s)
- Reversing drill motor with a 5/16" drill bit
- Hammer
- #2 Phillips screwdriver

STEP 1. Remove the affected ski binding from the ski.

STEP 2. Locate hole to be inserted. Using a reversing drill motor with a 5/16" drill bit, **IN REVERSE**, drill a hole approximately 3/8" deep. **DO NOT** drill in normal forward direction.

STEP 3. Lightly tap the small hole end of the insert into the newly drilled hole.

STEP 4. Repeat Steps 2-3 as needed.

STEP 5. Replace binding and fasten using #10 x 5/8" stainless steel sheet metal screws.

NOTE: When installed properly, the inserts will provide retention to factory standards. It is advisable, to ensure good binding retention, to add additional screws, without inserts, spaced a minimum of one (1) hole apart from the newly inserted holes. This double-ups the number of screws normally holding your binding on the ski.